

Configuring Permissions

Permissions are used in sipXecs to control what individual users are allowed to do. We distinguish between **general permissions** and **call permissions**. The distinction between the two is not always perfectly intuitive, but generally call permissions influence call routing privileges (i.e. access to dial plan) where general permissions determine access to system functions.

Managing User Permissions

General permissions include user privileges such as system administrator rights and the ability to change the PIN from the telephone interface. A default value is assigned to every newly created user. This default can be changed by the system admin on a per user basis or on a user group level.

User: 204

General Permission

Identification	Superadmin Access	<input type="checkbox"/>	(Default: unchecked)
Call Forwarding			User can log into administration interface.
General Permission	Change PIN from IVR	<input checked="" type="checkbox"/>	(Default: checked)
Call Permission			User can change PIN value from Voicemail system. PIN is used to log into voicemail system and web interface. PIN does not affect the password phones use to authenticate with registration server.
Caller ID			
Group Supervisor			

OK Apply Cancel

Call permissions include privileges as they apply to the dial plan. They determine rights to make calls to certain destinations, such as long distance, 900 numbers, mobile phones, 800 numbers, international calls, etc. Call permissions also determine whether the user has a voicemail box, is included in the auto-attendant dial-by-name feature, or can record system prompts.

Especially the voicemail box permission is important not just for the voicemail function itself. E.g. if the user is part of a hunt group then the call sequence could be different dependent on whether the system can transfer to voicemail for a particular user or not.

Users	Devices	Features	System	Diagnostics
<ul style="list-style-type: none"> > Identification > Phones > Call Forwarding > Schedules > Speed Dial > Group Supervisor > Personal AutoAttendant > Registrations ▶ Permissions > Caller ID 	<p>User: 301</p> <p>Permissions</p> <p>General Permission</p> <p>Superadmin Access <input type="checkbox"/> (Default: unchecked) User can log into administration interface.</p> <p>Change PIN from IVR <input checked="" type="checkbox"/> (Default: checked) User can change PIN value from Voicemail system. PIN is used to log into voicemail system and web interface. PIN does not affect the password phones use to authenticate with registration server.</p> <p>Configure Personal Auto Attendant <input checked="" type="checkbox"/> (Default: checked) User can configure personal auto attendant</p> <p>Call Permission</p> <p>900 Dialing <input type="checkbox"/> (Default: unchecked) User can dial 900 numbers</p> <p>Attendant Directory <input type="checkbox"/> (Default: unchecked) List user in Auto Attendant</p> <p>International Dialing <input checked="" type="checkbox"/> (Default: checked) User can dial international numbers</p> <p>Local Dialing <input checked="" type="checkbox"/> (Default: checked) User can dial local numbers</p> <p>Long Distance Dialing <input checked="" type="checkbox"/> (Default: checked) User can dial long distance numbers</p> <p>Mobile Dialing <input checked="" type="checkbox"/> (Default: checked) User can dial mobile numbers</p> <p>Toll Free <input checked="" type="checkbox"/> (Default: checked) User can dial toll free numbers</p> <p>Voice Mail <input checked="" type="checkbox"/> (Default: checked) User has voicemail inbox</p> <p>Record System Prompts <input type="checkbox"/> (Default: unchecked) User can record system prompts</p> <p>Voicemail Server</p> <p>Only one voicemail server permission should be chosen at a time</p> <p>Internal Voicemail Server <input checked="" type="checkbox"/> (Default: checked) User has permissions for Internal Voicemail Server</p> <p>Microsoft Exchange UM Voicemail Server <input type="checkbox"/> (Default: unchecked) User has permissions for Microsoft Exchange UM Voicemail Server</p> <p>OK Apply Cancel</p>			

Managing Permissions at the User Group Level

Permissions can also be defined at the user group level. They then apply to all the user that are members of that group. If users are members of several groups that have different permission settings, then the setting from the last group applies. Settings at the user level override settings at the group level.

Defining and Using Custom Permissions

In addition to the built-in system permissions described above, sipXecs allows the administrator to define additional custom permissions. These custom permissions can be used in dial plan routing rules in the same way built-in permissions are used. This feature is very helpful e.g. when localizing sipXecs to adapt to other countries dial plans as these countries might require additional privileges to make call to certain categories of service numbers.

Permissions

[Add Permission](#)

Name	Default value	Description
900 Dialing	Disabled	User can dial 900 numbers
Attendant Directory	Disabled	List user in Auto Attendant
Forward Calls External	Disabled	User can forward calls to external numbers
International Dialing	Enabled	User can dial international numbers
Local Dialing	Enabled	User can dial local numbers
Long Distance Dialing	Enabled	User can dial long distance numbers
Mobile Dialing	Enabled	User can dial mobile numbers
Record System Prompts	Disabled	User can record system prompts
Toll Free	Enabled	User can dial toll free numbers
Voice Mail	Enabled	User has voicemail inbox

Quick Links

[Dial Plans](#)

Permissions defined here can be used when defining dialing plan rules. Built-in permissions cannot be changed or removed. You can enable and disable permissions on User and User Group permission screen.

Built-in permissions cannot be deleted or disabled.

The screen for defining a new custom permission looks as follows. It is possible to define as many custom permissions as needed.

Permission

Name

Permission name is displayed on User Call Permission screen and on Dial Rule edit screen.

Description

Default value

If checked this permission is enabled by default.