

LGNortel Phones

Standard setup

Either set TFTP address in your DHCP configuration or set it from the phone's web interface.

Accessing web interface

```
http://ip-address:8000
```

Default admin access user name is **private** and password is **lip**

Note: The Opera browser is not able to interact with this phone's java scripts.