

# Configuring Caller ID to the PSTN

sipXecs has a set of flexible mechanisms to configure Caller ID (CLID). Caller ID can be defined per user, on a user group level, or per gateway. In addition, Caller ID can be set by a transformation of the internal line number, on a per gateway basis, to strip leading digits and add a new prefix. This allows different Caller ID values to be sent for the same user depending on the gateway the call is routed through (for example, a call to London through the London gateway could send a different Caller ID than a call to Los Angeles through the local gateway there).

Caller ID can also be blocked on a per user or per gateway basis (CLIR).



Especially for emergency services calls (such as 911 in North America), there may be very specific legal requirements for what you send as caller id in the jurisdictions you are in: it is **your** responsibility to make sure that you are meeting those requirements when you route these calls.



The sipXecs proxy can manipulate what it sends to your connection to the PSTN, but different PSTN connections have different capabilities in terms of what is possible from there:

- If you have an analog line, the caller id will always just be the number associated with that line: *nothing that sipXecs does will make any difference.*
- If you have a T1 style connection through a gateway device, your terms of service and the capabilities and configuration of your gateway affect what will be presented on the PSTN.
- If you use a SIP Trunk, then the configuration of your SIP trunk and how your provider passes the call on to the PSTN affect what will be presented.

Getting all this to work so that the id presented by the PSTN is what you want it to be may take some experimentation and reconfiguration. See [# What caller id is in SIP](#) below.

## Gateway level Caller ID

There are a few different ways of manipulating the caller id that is sent to a given gateway; each of these apply to any call sent out through that gateway. Normally, any of these settings may be overridden by settings that are specific to a particular user as described [below](#); to prevent a user-specified value from overriding the gateway value, check the 'Ignore user Caller ID' checkbox.

### GATEWAY DETAILS

Configuration	Gateway : <u>unmanagedgw</u> / Unmanaged gateway
<b>Caller ID</b>	Default Caller ID <input type="text"/>
Dial Plan	Display name <input type="text"/>
	URL parameters <input type="text"/>
	Block Caller ID <input type="checkbox"/>
	Ignore user Caller ID <input type="checkbox"/>
	Transform extension <input type="checkbox"/>
	Caller ID prefix <input type="text"/>
	Keep digits <input type="text" value="0"/>

OK Apply Cancel

### GATEWAY DETAILS

Configuration	Gateway : <u>siptrunk</u> / SIP trunk
<b>Caller ID</b>	Default Caller ID <input type="text"/>
Dial Plan	Display name <input type="text"/>
ITSP Account	URL parameters <input type="text"/>
	Block Caller ID <input type="checkbox"/>
	Ignore user Caller ID <input type="checkbox"/>
	Transform extension <input type="checkbox"/>
	Caller ID prefix <input type="text"/>
	Keep digits <input type="text" value="0"/>

OK Apply Cancel

## Setting a single Caller ID for all outbound calls

If you want all outgoing calls to have the same caller id (typically true if all or most users do not have a [DID](#) so incoming calls go to a single 'main' number), then you can associate the number you want with the gateway.

To set a single caller id, select a gateway and navigate to the Caller ID settings screen.

Fill in just the 'Default Caller Id' setting with the number you wish to send as your caller id.

## Blocking Caller ID for all calls

To always prevent any caller id from being sent, check only the 'Block Caller ID' checkbox.

## Transforming the callers extension into a Caller ID

If you have users who have individual Direct Inward Dial ([DID](#)) numbers, and those users' extensions can be mapped to the DID numbers using some pattern, then you can configure the pattern once at the gateway. To do this transformation, check the 'Transform extension' checkbox, and then set the following two fields:

**Keep digits:** this is the number of *trailing* digits of the calling extension to retain in the caller id. If zero is specified, then all digits are kept.

**Caller ID prefix:** this is a fixed number to add *in front of* the remaining digits.


So, for example, to transform the internal extension 5432 into the caller id 9785556432, you would set:

*Keep digits:* 3

*Caller ID prefix:* 9785556

## User specific Caller ID

If you have some users whose extensions cannot be transformed by a pattern to the Caller ID value you want for them, you can set a specific value on the User Caller ID screen; as with the gateway, you can check the 'Block Caller ID' to make all calls made by the user anonymous:



The screenshot shows a web interface for configuring a user's Caller ID. The page title is 'CALLER ID'. On the left is a navigation menu with items: Identification, Unified Messaging, Contact Information, Phones, Call Forwarding, Schedules, Speed Dial, Personal Auto-Attendant, Conferences, Registrations, Music On Hold, Time Zone, Hoteling, E911 Location, Permissions, **Caller ID** (highlighted), Domain, Instant Messaging, and User Portal. The main content area is titled 'User: 201' and 'Caller ID'. It contains a text input field for 'Caller ID', a 'Block Caller ID' checkbox (which is unchecked), and a note: 'Externally visible user Caller ID. If it is not specified the gateway will create a Caller ID based on the caller's extension and additional gateway parameters. (Default: unchecked)'. Below the checkbox is the text 'Block Caller ID for external calls for all calls made by this user.' At the bottom of the main area are three buttons: 'OK', 'Apply', and 'Cancel'.

Unless the gateway configuration has set the 'Ignore user Caller ID' flag, a user specific value takes precedence over the value set by a gateway.

## Group Caller ID

Caller ID can also be defined at the User Group level. If set in the group and not overridden by the specific user, all users in the group share the same caller ID number for outgoing calls.

**USER GROUP SETTINGS**

- Configure
- Unified Messaging
- Schedules
- Conference
- External User
- Speed Dials
- Time Zone
- Music On Hold
- Hoteling
- E911 Location
- Permissions
- Caller ID**
- Personal Auto-Attendant
- Domain
- Instant Messaging
- Call Forwarding
- User Portal

**Caller ID**

Caller ID

Externally visible user Caller ID. If it is not specified the gateway will create a Caller ID based on the caller's extension and additional gateway parameters.

Block Caller ID  (Default: unchecked)

Block Caller ID for external calls for all calls made by this user.

As with any group setting, if a user is in several groups, the setting of the last group is the one that controls the active caller id.

## What caller id is in SIP

The nearest equivalent to the PSTN caller id in SIP is the 'From' header field, which can include both a Display Name (set in sipXecs on most phones from the first and last name fields of the user), and a number - carried as the part of the sip address between 'sip:' and the '@' character.

When you configure a Caller ID, the 'From' header field in the SIP message for outgoing calls is modified by the sipXecs proxy according to the mechanisms described above.

When you configure that Caller ID should be blocked, the 'From' header field is set to 'sip:anonymous@anonymous.invalid' (a special value defined by the SIP standards).

**Between that From header field sent by sipXecs and the caller id display on the phone of the person you are calling are any number of possible transformations.** It may be that it will require reconfiguration of one or more of the elements of that signaling path to get the result you want, and it may be that some part of your connection will prevent what you want. It will probably be helpful to verify how sipXecs is setting the value; to trace this, see [Display SIP Message flow using Sipviewer](#).